WORK INSTRUCTION

Document ID: DOC-0001600
Project: PRJ-016
Uploaded on: 2024-12-02
Uploaded by: user099
Export class: EAR99

Assembly of P-101895 at plant PLT01

Part Number: P-101895
Revision: A.1
Plant: PLT01
Station: ST-36
Torque (Nm): 5
Cycle time (s): 234

Step 1: Move to next station

Step 2: Move to next station

Step 3: Apply thread locker

Step 4: Apply thread locker

Step 5: Torque to specification

Step 6: Torque to specification

Step 7: Record result

Step 8: Move to next station

Assembly of P-100125 at plant PLT01

Part Number: P-100125
Revision: A.1
Plant: PLT01
Station: ST-16
Torque (Nm): 20
Cycle time (s): 31

Step 1: Move to next station

Step 2: Torque to specification

Step 3: Move to next station

Step 4: Clean mating surface

Step 5: Record result

Step 6: Fit fasteners