# WORK INSTRUCTION

**Document ID:** DOC-0001267
**Project:** PRJ-023
**Uploaded on:** 2024-07-15
**Uploaded by:** user064
**Export class:** EAR99

## Assembly of P-100290 at plant PLT03

**Part Number:** P-100290
**Revision:** A.1
**Plant:** PLT03
**Station:** ST-97
**Torque (Nm):** 2.5
**Cycle time (s):** 40

Step 1: Record result

Step 2: Clean mating surface

Step 3: Apply thread locker

Step 4: Fit fasteners

Step 5: Apply thread locker

## Assembly of P-100832 at plant PLT02

**Part Number:** P-100832
**Revision:** A.1
**Plant:** PLT02
**Station:** ST-90
**Torque (Nm):** 20
**Cycle time (s):** 207

Step 1: Apply thread locker

Step 2: Torque to specification

Step 3: Clean mating surface

Step 4: Clean mating surface

Step 5: Fit fasteners

Step 6: Move to next station