WORK INSTRUCTION

Document ID: DOC-0001283
Project: PRJ-014
Uploaded on: 2024-07-19
Uploaded by: user010
Export class: EAR99

Assembly of P-101122 at plant PLT01

Part Number: P-101122
Revision: A.1
Plant: PLT01
Station: ST-83
Torque (Nm): 12
Cycle time (s): 240

Step 1: Fit fasteners

Step 2: Inspect incoming part

Step 3: Move to next station

Step 4: Move to next station

Step 5: Torque to specification

Step 6: Visual check

Step 7: Apply thread locker