WORK INSTRUCTION

Document ID: DOC-0000628
Project: PRJ-035
Uploaded on: 2023-08-26
Uploaded by: user012
Export class: EAR99

Assembly of P-100257 at plant PLT02

Part Number: P-100257
Revision: A.1
Plant: PLT02
Station: ST-14
Torque (Nm): 20
Cycle time (s): 60

Step 1: Inspect incoming part

Step 2: Clean mating surface

Step 3: Inspect incoming part

Step 4: Apply thread locker

Step 5: Fit fasteners

Step 6: Apply thread locker

Step 7: Fit fasteners

Step 8: Torque to specification