# WORK INSTRUCTION

**Document ID:** DOC-0000896
**Project:** PRJ-007
**Uploaded on:** 2024-01-19
**Uploaded by:** user034
**Export class:** EAR99

## Assembly of P-100691 at plant PLT01

**Part Number:** P-100691
**Revision:** A.1
**Plant:** PLT01
**Station:** ST-16
**Torque (Nm):** 8
**Cycle time (s):** 40

Step 1: Move to next station

Step 2: Apply thread locker

Step 3: Apply thread locker

Step 4: Visual check

Step 5: Torque to specification

Step 6: Inspect incoming part

Step 7: Fit fasteners

## Assembly of P-100702 at plant PLT01

**Part Number:** P-100702
**Revision:** B.1
**Plant:** PLT01
**Station:** ST-40
**Torque (Nm):** 2.5
**Cycle time (s):** 144

Step 1: Clean mating surface

Step 2: Clean mating surface

Step 3: Inspect incoming part

Step 4: Torque to specification

Step 5: Move to next station

Step 6: Inspect incoming part

Step 7: Clean mating surface

## Assembly of P-100465 at plant PLT01

**Part Number:** P-100465
**Revision:** A.1
**Plant:** PLT01
**Station:** ST-34
**Torque (Nm):** 8

**Cycle time (s):** 120

Step 1: Inspect incoming part

Step 2: Inspect incoming part

Step 3: Move to next station

Step 4: Clean mating surface

Step 5: Torque to specification

Step 6: Apply thread locker

Step 7: Record result