WORK INSTRUCTION

Document ID: DOC-0001837
Project: PRJ-020
Uploaded on: 2025-03-23
Uploaded by: user086
Export class: EAR99

Assembly of P-102639 at plant PLT01

Part Number: P-102639
Revision: A.1
Plant: PLT01
Station: ST-26
Torque (Nm): 2.5
Cycle time (s): 280

Step 1: Move to next station

Step 2: Record result

Step 3: Apply thread locker

Step 4: Torque to specification

Step 5: Torque to specification

Step 6: Visual check

Step 7: Visual check

Step 8: Fit fasteners

Assembly of P-101964 at plant PLT01

Part Number: P-101964
Revision: B.1
Plant: PLT01
Station: ST-53
Torque (Nm): 20
Cycle time (s): 256

Step 1: Visual check

Step 2: Torque to specification

Step 3: Apply thread locker

Step 4: Fit fasteners

Step 5: Record result

Step 6: Apply thread locker

Step 7: Visual check

Assembly of P-100913 at plant PLT03

Part Number: P-100913
Revision: A.1
Plant: PLT03
Station: ST-39

Torque (Nm):	20
Cycle time (s):	248

Step 1: Move to next station

Step 2: Fit fasteners

Step 3: Fit fasteners

Step 4: Inspect incoming part

Step 5: Move to next station

Step 6: Record result