EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0001735
Project: PRJ-031
Uploaded on: 2025-02-10
Uploaded by: user085
Export class: ECCN-3A001

Assembly of P-100249 at plant PLT01

Part Number: P-100249
Revision: C.1
Plant: PLT01
Station: ST-39
Torque (Nm): 5
Cycle time (s): 86

Step 1: Fit fasteners

Step 2: Apply thread locker

Step 3: Clean mating surface

Step 4: Move to next station

Step 5: Record result

Step 6: Visual check

Assembly of P-100767 at plant PLT04

Part Number: P-100767
Revision: A.1
Plant: PLT04
Station: ST-77
Torque (Nm): 20
Cycle time (s): 201

Step 1: Visual check

Step 2: Fit fasteners

Step 3: Record result

Step 4: Clean mating surface

Step 5: Move to next station

Assembly of P-100423 at plant PLT02

Part Number: P-100423
Revision: B.1
Plant: PLT02
Station: ST-31
Torque (Nm): 12
Cycle time (s): 280

Step 1: Record result

Step 2: Inspect incoming part

Step 3: Torque to specification

Step 4: Move to next station

Step 5: Inspect incoming part

Step 6: Torque to specification

Step 7: Fit fasteners