WORK INSTRUCTION

Document ID: DOC-0001786
Project: PRJ-010
Uploaded on: 2025-03-03
Uploaded by: user134
Export class: EAR99

Assembly of P-100564 at plant PLT03

Part Number: P-100564
Revision: A.1
Plant: PLT03
Station: ST-39
Torque (Nm): 2.5
Cycle time (s): 117

Step 1: Move to next station

Step 2: Move to next station

Step 3: Record result

Step 4: Apply thread locker

Step 5: Fit fasteners

Step 6: Clean mating surface

Step 7: Visual check