WORK INSTRUCTION

Document ID: DOC-0002818
Project: PRJ-040
Uploaded on: 2026-07-08
Uploaded by: user078
Export class: EAR99

Assembly of P-100452 at plant PLT01

Part Number: P-100452
Revision: B.1
Plant: PLT01
Station: ST-83
Torque (Nm): 12
Cycle time (s): 284

Step 1: Clean mating surface

Step 2: Fit fasteners

Step 3: Move to next station

Step 4: Record result

Step 5: Torque to specification

Step 6: Fit fasteners

Step 7: Fit fasteners

Step 8: Clean mating surface