WORK INSTRUCTION

Document ID: DOC-0002346
Project: PRJ-003
Uploaded on: 2025-11-28
Uploaded by: user161
Export class: EAR99

Assembly of P-100854 at plant PLT03

Part Number: P-100854
Revision: A.1
Plant: PLT03
Station: ST-16
Torque (Nm): 20
Cycle time (s): 299

Step 1: Fit fasteners

Step 2: Fit fasteners

Step 3: Clean mating surface

Step 4: Move to next station

Step 5: Fit fasteners

Step 6: Fit fasteners