WORK INSTRUCTION

Document ID: DOC-0002372
Project: PRJ-025
Uploaded on: 2025-12-10
Uploaded by: user149
Export class: EAR99

Assembly of P-100885 at plant PLT01

Part Number: P-100885
Revision: B.1
Plant: PLT01
Station: ST-44
Torque (Nm): 8
Cycle time (s): 157

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Clean mating surface

Step 4: Apply thread locker

Step 5: Clean mating surface

Step 6: Clean mating surface

Step 7: Record result

Step 8: Apply thread locker