EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0002378
Project: PRJ-031
Uploaded on: 2025-12-12
Uploaded by: user084
Export class: ECCN-3A001

Assembly of P-101833 at plant PLT03

Part Number: P-101833
Revision: A.1
Plant: PLT03
Station: ST-37
Torque (Nm): 8
Cycle time (s): 196

Step 1: Record result

Step 2: Record result

Step 3: Clean mating surface

Step 4: Clean mating surface

Step 5: Apply thread locker

Assembly of P-101888 at plant PLT03

Part Number: P-101888
Revision: C.1
Plant: PLT03
Station: ST-87
Torque (Nm): 12
Cycle time (s): 130

Step 1: Torque to specification

Step 2: Move to next station

Step 3: Fit fasteners

Step 4: Record result

Step 5: Fit fasteners

Step 6: Inspect incoming part