WORK INSTRUCTION

Document ID: DOC-0002382
Project: PRJ-002
Uploaded on: 2025-12-13
Uploaded by: user176
Export class: EAR99

Assembly of P-103065 at plant PLT01

Part Number: P-103065
Revision: A.1
Plant: PLT01
Station: ST-75
Torque (Nm): 2.5
Cycle time (s): 216

Step 1: Apply thread locker

Step 2: Torque to specification

Step 3: Fit fasteners

Step 4: Fit fasteners

Step 5: Record result

Step 6: Fit fasteners

Assembly of P-100151 at plant PLT02

Part Number: P-100151
Revision: B.1
Plant: PLT02
Station: ST-32
Torque (Nm): 12
Cycle time (s): 88

Step 1: Fit fasteners

Step 2: Move to next station

Step 3: Apply thread locker

Step 4: Inspect incoming part

Step 5: Torque to specification

Step 6: Apply thread locker

Step 7: Move to next station