WORK INSTRUCTION

Document ID: DOC-0002401
Project: PRJ-012
Uploaded on: 2025-12-22
Uploaded by: user065
Export class: EAR99

Assembly of P-101581 at plant PLT03

Part Number: P-101581
Revision: A.1
Plant: PLT03
Station: ST-93
Torque (Nm): 20
Cycle time (s): 192

Step 1: Apply thread locker

Step 2: Fit fasteners

Step 3: Move to next station

Step 4: Clean mating surface

Step 5: Clean mating surface