WORK INSTRUCTION

Document ID: DOC-0000856
Project: PRJ-023
Uploaded on: 2023-12-17
Uploaded by: user172
Export class: EAR99

Assembly of P-100142 at plant PLT04

Part Number: P-100142
Revision: D.1
Plant: PLT04
Station: ST-12
Torque (Nm): 2.5
Cycle time (s): 297

Step 1: Move to next station

Step 2: Apply thread locker

Step 3: Apply thread locker

Step 4: Apply thread locker

Step 5: Clean mating surface

Step 6: Fit fasteners

Step 7: Inspect incoming part

Step 8: Fit fasteners

Assembly of P-100601 at plant PLT02

Part Number: P-100601
Revision: A.1
Plant: PLT02
Station: ST-87
Torque (Nm): 2.5
Cycle time (s): 232

Step 1: Fit fasteners

Step 2: Apply thread locker

Step 3: Apply thread locker

Step 4: Fit fasteners

Step 5: Clean mating surface

Step 6: Move to next station

Step 7: Move to next station

Step 8: Fit fasteners