EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0000345
Project: PRJ-037
Uploaded on: 2023-04-15
Uploaded by: user178
Export class: ECCN-3A001

Assembly of P-100500 at plant PLT04

Part Number: P-100500
Revision: A.1
Plant: PLT04
Station: ST-56
Torque (Nm): 20
Cycle time (s): 56

Step 1: Torque to specification

Step 2: Move to next station

Step 3: Record result

Step 4: Apply thread locker

Step 5: Fit fasteners

Step 6: Visual check

Step 7: Record result

Step 8: Move to next station

Assembly of P-100408 at plant PLT04

Part Number: P-100408
Revision: A.1
Plant: PLT04
Station: ST-48
Torque (Nm): 20
Cycle time (s): 153

Step 1: Record result

Step 2: Apply thread locker

Step 3: Inspect incoming part

Step 4: Apply thread locker

Step 5: Fit fasteners

Assembly of P-100346 at plant PLT03

Part Number: P-100346
Revision: A.1
Plant: PLT03
Station: ST-70

Torque (Nm):	5
Cycle time (s):	193

Step 1: Visual check

Step 2: Visual check

Step 3: Apply thread locker

Step 4: Torque to specification

Step 5: Apply thread locker

Step 6: Clean mating surface

Step 7: Apply thread locker

Step 8: Fit fasteners