WORK INSTRUCTION

Document ID: DOC-0000380
Project: PRJ-008
Uploaded on: 2023-05-01
Uploaded by: user189
Export class: EAR99

Assembly of P-100157 at plant PLT03

Part Number: P-100157
Revision: A.1
Plant: PLT03
Station: ST-54
Torque (Nm): 5
Cycle time (s): 139

Step 1: Visual check

Step 2: Fit fasteners

Step 3: Visual check

Step 4: Inspect incoming part

Step 5: Visual check

Step 6: Fit fasteners

Step 7: Torque to specification

Step 8: Move to next station

Assembly of P-100554 at plant PLT02

Part Number: P-100554
Revision: A.1
Plant: PLT02
Station: ST-65
Torque (Nm): 2.5
Cycle time (s): 61

Step 1: Inspect incoming part

Step 2: Fit fasteners

Step 3: Fit fasteners

Step 4: Apply thread locker

Step 5: Clean mating surface

Step 6: Torque to specification

Step 7: Move to next station

Step 8: Apply thread locker