EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0000590
Project: PRJ-036
Uploaded on: 2023-08-09
Uploaded by: user018
Export class: ECCN-3A001

Assembly of P-100847 at plant PLT03

Part Number: P-100847
Revision: A.1
Plant: PLT03
Station: ST-91
Torque (Nm): 12
Cycle time (s): 93

Step 1: Torque to specification

Step 2: Record result

Step 3: Inspect incoming part

Step 4: Visual check

Step 5: Inspect incoming part

Step 6: Record result

Step 7: Move to next station

Assembly of P-100026 at plant PLT01

Part Number: P-100026
Revision: B.1
Plant: PLT01
Station: ST-46
Torque (Nm): 12
Cycle time (s): 195

Step 1: Move to next station

Step 2: Visual check

Step 3: Inspect incoming part

Step 4: Move to next station

Step 5: Torque to specification

Step 6: Inspect incoming part

Assembly of P-100439 at plant PLT02

Part Number: P-100439
Revision: A.1
Plant: PLT02
Station: ST-74

Torque (Nm): 12
Cycle time (s): 57

Step 1: Record result

Step 2: Record result

Step 3: Record result

Step 4: Clean mating surface

Step 5: Inspect incoming part

Step 6: Fit fasteners

Step 7: Record result