EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0001363
Project: PRJ-029
Uploaded on: 2024-08-20
Uploaded by: user193
Export class: ECCN-3A001

Assembly of P-101844 at plant PLT03

Part Number: P-101844
Revision: A.1
Plant: PLT03
Station: ST-83
Torque (Nm): 5
Cycle time (s): 185

Step 1: Torque to specification

Step 2: Inspect incoming part

Step 3: Move to next station

Step 4: Clean mating surface

Step 5: Apply thread locker

Step 6: Apply thread locker

Step 7: Clean mating surface

Assembly of P-102196 at plant PLT02

Part Number: P-102196
Revision: A.1
Plant: PLT02
Station: ST-34
Torque (Nm): 20
Cycle time (s): 252

Step 1: Visual check

Step 2: Clean mating surface

Step 3: Torque to specification

Step 4: Apply thread locker

Step 5: Visual check

Step 6: Inspect incoming part