WORK INSTRUCTION

Document ID: DOC-0001700
Project: PRJ-040
Uploaded on: 2025-01-22
Uploaded by: user156
Export class: EAR99

Assembly of P-100798 at plant PLT03

Part Number: P-100798
Revision: B.1
Plant: PLT03
Station: ST-25
Torque (Nm): 2.5
Cycle time (s): 109

Step 1: Apply thread locker

Step 2: Torque to specification

Step 3: Torque to specification

Step 4: Fit fasteners

Step 5: Inspect incoming part

Step 6: Apply thread locker

Step 7: Torque to specification

Step 8: Move to next station

Assembly of P-102549 at plant PLT04

Part Number: P-102549
Revision: A.1
Plant: PLT04
Station: ST-31
Torque (Nm): 12
Cycle time (s): 132

Step 1: Record result

Step 2: Torque to specification

Step 3: Move to next station

Step 4: Apply thread locker

Step 5: Inspect incoming part

Step 6: Clean mating surface

Step 7: Apply thread locker

Step 8: Move to next station