WORK INSTRUCTION

Document ID: DOC-0001707
Project: PRJ-036
Uploaded on: 2025-01-28
Uploaded by: user105
Export class: EAR99

Assembly of P-100362 at plant PLT02

Part Number: P-100362
Revision: C.1
Plant: PLT02
Station: ST-30
Torque (Nm): 20
Cycle time (s): 235

Step 1: Record result

Step 2: Fit fasteners

Step 3: Clean mating surface

Step 4: Inspect incoming part

Step 5: Inspect incoming part

Step 6: Inspect incoming part

Assembly of P-100823 at plant PLT01

Part Number: P-100823
Revision: A.1
Plant: PLT01
Station: ST-57
Torque (Nm): 5
Cycle time (s): 148

Step 1: Move to next station

Step 2: Move to next station

Step 3: Inspect incoming part

Step 4: Record result

Step 5: Inspect incoming part

Step 6: Visual check

Step 7: Inspect incoming part

Step 8: Move to next station