WORK INSTRUCTION

Document ID: DOC-0001730
Project: PRJ-040
Uploaded on: 2025-02-04
Uploaded by: user115
Export class: EAR99

Assembly of P-102766 at plant PLT03

Part Number: P-102766
Revision: A.1
Plant: PLT03
Station: ST-35
Torque (Nm): 20
Cycle time (s): 257

Step 1: Visual check

Step 2: Torque to specification

Step 3: Record result

Step 4: Apply thread locker

Step 5: Apply thread locker

Step 6: Inspect incoming part

Step 7: Fit fasteners

Assembly of P-100063 at plant PLT01

Part Number: P-100063
Revision: C.1
Plant: PLT01
Station: ST-17
Torque (Nm): 5
Cycle time (s): 278

Step 1: Fit fasteners

Step 2: Torque to specification

Step 3: Visual check

Step 4: Move to next station

Step 5: Fit fasteners