WORK INSTRUCTION

Document ID: DOC-0002451
Project: PRJ-038
Uploaded on: 2026-01-14
Uploaded by: user127
Export class: EAR99

Assembly of P-100260 at plant PLT01

Part Number: P-100260
Revision: A.1
Plant: PLT01
Station: ST-52
Torque (Nm): 12
Cycle time (s): 98

Step 1: Inspect incoming part

Step 2: Apply thread locker

Step 3: Fit fasteners

Step 4: Move to next station

Step 5: Record result

Step 6: Clean mating surface