WORK INSTRUCTION

Document ID: DOC-0002453
Project: PRJ-028
Uploaded on: 2026-01-16
Uploaded by: user188
Export class: EAR99

Assembly of P-101234 at plant PLT02

Part Number: P-101234
Revision: A.1
Plant: PLT02
Station: ST-86
Torque (Nm): 20
Cycle time (s): 147

Step 1: Clean mating surface

Step 2: Fit fasteners

Step 3: Move to next station

Step 4: Move to next station

Step 5: Record result

Step 6: Inspect incoming part

Step 7: Apply thread locker