WORK INSTRUCTION

Document ID: DOC-0002456
Project: PRJ-006
Uploaded on: 2026-01-17
Uploaded by: user059
Export class: EAR99

Assembly of P-102768 at plant PLT03

Part Number: P-102768
Revision: A.1
Plant: PLT03
Station: ST-71
Torque (Nm): 20
Cycle time (s): 186

Step 1: Record result

Step 2: Record result

Step 3: Apply thread locker

Step 4: Inspect incoming part

Step 5: Clean mating surface

Step 6: Fit fasteners