WORK INSTRUCTION

Document ID: DOC-0002475
Project: PRJ-006
Uploaded on: 2026-01-25
Uploaded by: user041
Export class: EAR99

Assembly of P-103728 at plant PLT03

Part Number: P-103728
Revision: A.1
Plant: PLT03
Station: ST-56
Torque (Nm): 2.5
Cycle time (s): 201

Step 1: Fit fasteners

Step 2: Move to next station

Step 3: Apply thread locker

Step 4: Inspect incoming part

Step 5: Apply thread locker

Step 6: Apply thread locker

Step 7: Fit fasteners

Step 8: Visual check

Assembly of P-103911 at plant PLT02

Part Number: P-103911
Revision: A.1
Plant: PLT02
Station: ST-27
Torque (Nm): 20
Cycle time (s): 83

Step 1: Apply thread locker

Step 2: Apply thread locker

Step 3: Inspect incoming part

Step 4: Fit fasteners

Step 5: Visual check

Step 6: Inspect incoming part