EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0002206
Project: PRJ-029
Uploaded on: 2025-09-20
Uploaded by: user023
Export class: ECCN-3A001

Assembly of P-100008 at plant PLT01

Part Number: P-100008
Revision: A.1
Plant: PLT01
Station: ST-15
Torque (Nm): 2.5
Cycle time (s): 64

Step 1: Inspect incoming part

Step 2: Apply thread locker

Step 3: Fit fasteners

Step 4: Inspect incoming part

Step 5: Apply thread locker

Step 6: Inspect incoming part

Assembly of P-102461 at plant PLT02

Part Number: P-102461
Revision: A.1
Plant: PLT02
Station: ST-94
Torque (Nm): 2.5
Cycle time (s): 151

Step 1: Record result

Step 2: Record result

Step 3: Clean mating surface

Step 4: Record result

Step 5: Apply thread locker

Step 6: Record result

Step 7: Move to next station

Step 8: Apply thread locker