WORK INSTRUCTION

Document ID: DOC-0002577
Project: PRJ-028
Uploaded on: 2026-03-09
Uploaded by: user199
Export class: EAR99

Assembly of P-100504 at plant PLT02

Part Number: P-100504
Revision: B.1
Plant: PLT02
Station: ST-21
Torque (Nm): 5
Cycle time (s): 31

Step 1: Clean mating surface

Step 2: Fit fasteners

Step 3: Torque to specification

Step 4: Apply thread locker

Step 5: Torque to specification

Step 6: Torque to specification

Step 7: Record result