WORK INSTRUCTION

Document ID: DOC-0002949
Project: PRJ-020
Uploaded on: 2026-09-12
Uploaded by: user189
Export class: EAR99

Assembly of P-101268 at plant PLT01

Part Number: P-101268
Revision: A.1
Plant: PLT01
Station: ST-36
Torque (Nm): 20
Cycle time (s): 109

Step 1: Fit fasteners

Step 2: Clean mating surface

Step 3: Fit fasteners

Step 4: Clean mating surface

Step 5: Visual check

Step 6: Visual check

Step 7: Clean mating surface