EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0002950
Project: PRJ-025
Uploaded on: 2026-09-13
Uploaded by: user166
Export class: ECCN-3A001

Assembly of P-104003 at plant PLT03

Part Number: P-104003
Revision: A.1
Plant: PLT03
Station: ST-16
Torque (Nm): 2.5
Cycle time (s): 293

Step 1: Move to next station

Step 2: Fit fasteners

Step 3: Inspect incoming part

Step 4: Inspect incoming part

Step 5: Move to next station

Assembly of P-103965 at plant PLT04

Part Number: P-103965
Revision: A.1
Plant: PLT04
Station: ST-30
Torque (Nm): 20
Cycle time (s): 217

Step 1: Torque to specification

Step 2: Inspect incoming part

Step 3: Apply thread locker

Step 4: Visual check

Step 5: Inspect incoming part

Step 6: Move to next station

Assembly of P-100632 at plant PLT04

Part Number: P-100632
Revision: A.1
Plant: PLT04
Station: ST-89
Torque (Nm): 20
Cycle time (s): 127

Step 1: Torque to specification

Step 2: Torque to specification

Step 3: Record result

Step 4: Move to next station

Step 5: Torque to specification

Step 6: Fit fasteners