WORK INSTRUCTION

Document ID:	DOC-0001443
Project:	PRJ-025
Uploaded on:	2024-09-25
Uploaded by:	user030
Export class:	EAR99

Assembly of P-101604 at plant PLT04

Part Number:	P-101604
Revision:	A.1
Plant:	PLT04
Station:	ST-68
Torque (Nm):	20
Cycle time (s):	255

Step 1: Record result

Step 2: Fit fasteners

Step 3: Apply thread locker

Step 4: Apply thread locker

Step 5: Move to next station

Step 6: Torque to specification

Step 7: Record result

Step 8: Fit fasteners