WORK INSTRUCTION

Document ID: DOC-0000009
Project: PRJ-033
Uploaded on: 2022-11-08
Uploaded by: user002
Export class: EAR99

Assembly of P-100011 at plant PLT04

Part Number: P-100011
Revision: A.1
Plant: PLT04
Station: ST-77
Torque (Nm): 20
Cycle time (s): 128

Step 1: Visual check

Step 2: Fit fasteners

Step 3: Visual check

Step 4: Inspect incoming part

Step 5: Apply thread locker

Step 6: Fit fasteners

Assembly of P-100009 at plant PLT03

Part Number: P-100009
Revision: A.1
Plant: PLT03
Station: ST-55
Torque (Nm): 2.5
Cycle time (s): 176

Step 1: Apply thread locker

Step 2: Fit fasteners

Step 3: Record result

Step 4: Visual check

Step 5: Fit fasteners

Step 6: Record result

Assembly of P-100017 at plant PLT02

Part Number: P-100017
Revision: A.1
Plant: PLT02
Station: ST-91
Torque (Nm): 5
Cycle time (s): 282

Step 1: Inspect incoming part

Step 2: Clean mating surface

Step 3: Record result

Step 4: Apply thread locker

Step 5: Torque to specification