EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0000081
Project: PRJ-038
Uploaded on: 2022-12-13
Uploaded by: user070
Export class: ECCN-3A001

Assembly of P-100145 at plant PLT03

Part Number: P-100145
Revision: A.1
Plant: PLT03
Station: ST-71
Torque (Nm): 20
Cycle time (s): 298

Step 1: Record result

Step 2: Move to next station

Step 3: Record result

Step 4: Visual check

Step 5: Record result

Step 6: Apply thread locker

Step 7: Fit fasteners

Step 8: Clean mating surface

Assembly of P-100051 at plant PLT03

Part Number: P-100051
Revision: A.1
Plant: PLT03
Station: ST-97
Torque (Nm): 20
Cycle time (s): 146

Step 1: Record result

Step 2: Move to next station

Step 3: Clean mating surface

Step 4: Record result

Step 5: Torque to specification