WORK INSTRUCTION

Document ID: DOC-0000095
Project: PRJ-003
Uploaded on: 2022-12-20
Uploaded by: user053
Export class: EAR99

Assembly of P-100083 at plant PLT02

Part Number: P-100083
Revision: A.1
Plant: PLT02
Station: ST-63
Torque (Nm): 5
Cycle time (s): 283

Step 1: Move to next station

Step 2: Fit fasteners

Step 3: Inspect incoming part

Step 4: Fit fasteners

Step 5: Apply thread locker

Step 6: Torque to specification

Step 7: Apply thread locker

Step 8: Torque to specification

Assembly of P-100028 at plant PLT03

Part Number: P-100028
Revision: A.1
Plant: PLT03
Station: ST-17
Torque (Nm): 12
Cycle time (s): 103

Step 1: Fit fasteners

Step 2: Fit fasteners

Step 3: Torque to specification

Step 4: Inspect incoming part

Step 5: Fit fasteners

Step 6: Record result

Assembly of P-100054 at plant PLT03

Part Number: P-100054
Revision: A.1
Plant: PLT03
Station: ST-86
Torque (Nm): 8

Cycle time (s): 147

Step 1: Move to next station

Step 2: Fit fasteners

Step 3: Visual check

Step 4: Record result

Step 5: Clean mating surface

Step 6: Clean mating surface

Step 7: Clean mating surface