# WORK INSTRUCTION

**Document ID:** DOC-0000121
**Project:** PRJ-029
**Uploaded on:** 2023-01-01
**Uploaded by:** user174
**Export class:** EAR99

## Assembly of P-100022 at plant PLT03

**Part Number:** P-100022
**Revision:** A.1
**Plant:** PLT03
**Station:** ST-19
**Torque (Nm):** 20
**Cycle time (s):** 119

Step 1: Fit fasteners

Step 2: Move to next station

Step 3: Visual check

Step 4: Torque to specification

Step 5: Apply thread locker

Step 6: Inspect incoming part

Step 7: Move to next station

Step 8: Apply thread locker

## Assembly of P-100006 at plant PLT04

**Part Number:** P-100006
**Revision:** B.1
**Plant:** PLT04
**Station:** ST-94
**Torque (Nm):** 2.5
**Cycle time (s):** 78

Step 1: Visual check

Step 2: Torque to specification

Step 3: Clean mating surface

Step 4: Clean mating surface

Step 5: Clean mating surface