WORK INSTRUCTION

Document ID: DOC-0000139
Project: PRJ-019
Uploaded on: 2023-01-08
Uploaded by: user035
Export class: EAR99

Assembly of P-100108 at plant PLT03

Part Number: P-100108
Revision: A.1
Plant: PLT03
Station: ST-63
Torque (Nm): 5
Cycle time (s): 278

Step 1: Move to next station

Step 2: Record result

Step 3: Record result

Step 4: Fit fasteners

Step 5: Inspect incoming part

Step 6: Visual check

Assembly of P-100005 at plant PLT01

Part Number: P-100005
Revision: A.1
Plant: PLT01
Station: ST-62
Torque (Nm): 8
Cycle time (s): 39

Step 1: Move to next station

Step 2: Visual check

Step 3: Record result

Step 4: Clean mating surface

Step 5: Record result

Step 6: Inspect incoming part

Step 7: Inspect incoming part

Step 8: Move to next station