WORK INSTRUCTION

Document ID: DOC-0000167
Project: PRJ-035
Uploaded on: 2023-01-20
Uploaded by: user091
Export class: EAR99

Assembly of P-100089 at plant PLT02

Part Number: P-100089
Revision: A.1
Plant: PLT02
Station: ST-72
Torque (Nm): 20
Cycle time (s): 169

Step 1: Move to next station

Step 2: Torque to specification

Step 3: Apply thread locker

Step 4: Visual check

Step 5: Apply thread locker

Assembly of P-100225 at plant PLT04

Part Number: P-100225
Revision: A.1
Plant: PLT04
Station: ST-91
Torque (Nm): 8
Cycle time (s): 188

Step 1: Inspect incoming part

Step 2: Record result

Step 3: Apply thread locker

Step 4: Fit fasteners

Step 5: Clean mating surface

Step 6: Visual check

Step 7: Record result

Step 8: Fit fasteners

Assembly of P-100091 at plant PLT02

Part Number: P-100091
Revision: A.1
Plant: PLT02
Station: ST-74
Torque (Nm): 12
Cycle time (s): 136

Step 1: Fit fasteners

Step 2: Inspect incoming part

Step 3: Apply thread locker

Step 4: Inspect incoming part

Step 5: Torque to specification

Step 6: Apply thread locker

Step 7: Fit fasteners