# WORK INSTRUCTION

**Document ID:** DOC-0000198
**Project:** PRJ-040
**Uploaded on:** 2023-02-08
**Uploaded by:** user078
**Export class:** EAR99

## Assembly of P-100261 at plant PLT01

**Part Number:** P-100261
**Revision:** A.1
**Plant:** PLT01
**Station:** ST-88
**Torque (Nm):** 8
**Cycle time (s):** 136

Step 1: Inspect incoming part

Step 2: Fit fasteners

Step 3: Record result

Step 4: Inspect incoming part

Step 5: Apply thread locker

Step 6: Clean mating surface

Step 7: Clean mating surface

Step 8: Move to next station