**EXPORT CONTROLLED - ECCN 3A001**

# WORK INSTRUCTION

**Document ID:** DOC-0000345
**Project:** PRJ-037
**Uploaded on:** 2023-04-15
**Uploaded by:** user178
**Export class:** ECCN-3A001

## Assembly of P-100493 at plant PLT01

**Part Number:** P-100493
**Revision:** A.1
**Plant:** PLT01
**Station:** ST-56
**Torque (Nm):** 20
**Cycle time (s):** 56

Step 1: Torque to specification

Step 2: Move to next station

Step 3: Record result

Step 4: Apply thread locker

Step 5: Fit fasteners

Step 6: Visual check

Step 7: Record result

Step 8: Move to next station

## Assembly of P-100402 at plant PLT02

**Part Number:** P-100402
**Revision:** A.1
**Plant:** PLT02
**Station:** ST-48
**Torque (Nm):** 20
**Cycle time (s):** 153

Step 1: Record result

Step 2: Apply thread locker

Step 3: Inspect incoming part

Step 4: Apply thread locker

Step 5: Fit fasteners

## Assembly of P-100343 at plant PLT03

**Part Number:** P-100343
**Revision:** A.1
**Plant:** PLT03
**Station:** ST-70

| | |
|---|---|
| **Torque (Nm):** | 5 |
| **Cycle time (s):** | 193 |

Step 1: Visual check

Step 2: Visual check

Step 3: Apply thread locker

Step 4: Torque to specification

Step 5: Apply thread locker

Step 6: Clean mating surface

Step 7: Apply thread locker

Step 8: Fit fasteners