WORK INSTRUCTION

Document ID: DOC-0000432
Project: PRJ-008
Uploaded on: 2023-05-28
Uploaded by: user033
Export class: EAR99

Assembly of P-100161 at plant PLT02

Part Number: P-100161
Revision: A.1
Plant: PLT02
Station: ST-88
Torque (Nm): 12
Cycle time (s): 30

Step 1: Move to next station

Step 2: Record result

Step 3: Inspect incoming part

Step 4: Torque to specification

Step 5: Visual check

Step 6: Record result

Step 7: Record result

Assembly of P-100132 at plant PLT01

Part Number: P-100132
Revision: A.1
Plant: PLT01
Station: ST-87
Torque (Nm): 8
Cycle time (s): 237

Step 1: Record result

Step 2: Apply thread locker

Step 3: Apply thread locker

Step 4: Apply thread locker

Step 5: Torque to specification

Step 6: Visual check