WORK INSTRUCTION

Document ID: DOC-0000498
Project: PRJ-003
Uploaded on: 2023-06-22
Uploaded by: user029
Export class: EAR99

Assembly of P-100459 at plant PLT01

Part Number: P-100459
Revision: A.1
Plant: PLT01
Station: ST-81
Torque (Nm): 2.5
Cycle time (s): 242

Step 1: Visual check

Step 2: Apply thread locker

Step 3: Inspect incoming part

Step 4: Apply thread locker

Step 5: Fit fasteners

Assembly of P-100078 at plant PLT04

Part Number: P-100078
Revision: A.1
Plant: PLT04
Station: ST-68
Torque (Nm): 12
Cycle time (s): 250

Step 1: Visual check

Step 2: Inspect incoming part

Step 3: Torque to specification

Step 4: Visual check

Step 5: Inspect incoming part

Step 6: Record result