WORK INSTRUCTION

Document ID: DOC-0000539
Project: PRJ-021
Uploaded on: 2023-07-14
Uploaded by: user031
Export class: EAR99

Assembly of P-100040 at plant PLT02

Part Number: P-100040
Revision: A.1
Plant: PLT02
Station: ST-11
Torque (Nm): 2.5
Cycle time (s): 186

Step 1: Move to next station

Step 2: Apply thread locker

Step 3: Fit fasteners

Step 4: Inspect incoming part

Step 5: Fit fasteners

Step 6: Apply thread locker

Assembly of P-100821 at plant PLT01

Part Number: P-100821
Revision: A.1
Plant: PLT01
Station: ST-12
Torque (Nm): 12
Cycle time (s): 186

Step 1: Visual check

Step 2: Visual check

Step 3: Fit fasteners

Step 4: Torque to specification

Step 5: Move to next station