WORK INSTRUCTION

Document ID: DOC-0000610
Project: PRJ-035
Uploaded on: 2023-08-20
Uploaded by: user142
Export class: EAR99

Assembly of P-100389 at plant PLT03

Part Number: P-100389
Revision: A.1
Plant: PLT03
Station: ST-65
Torque (Nm): 12
Cycle time (s): 123

Step 1: Move to next station

Step 2: Move to next station

Step 3: Fit fasteners

Step 4: Visual check

Step 5: Record result

Step 6: Move to next station

Step 7: Clean mating surface

Step 8: Clean mating surface