WORK INSTRUCTION

Document ID: DOC-0000705
Project: PRJ-015
Uploaded on: 2023-10-06
Uploaded by: user157
Export class: EAR99

Assembly of P-100854 at plant PLT03

Part Number: P-100854
Revision: A.1
Plant: PLT03
Station: ST-53
Torque (Nm): 8
Cycle time (s): 85

Step 1: Torque to specification

Step 2: Inspect incoming part

Step 3: Move to next station

Step 4: Visual check

Step 5: Record result

Assembly of P-100908 at plant PLT03

Part Number: P-100908
Revision: A.1
Plant: PLT03
Station: ST-82
Torque (Nm): 2.5
Cycle time (s): 291

Step 1: Clean mating surface

Step 2: Fit fasteners

Step 3: Inspect incoming part

Step 4: Clean mating surface

Step 5: Visual check

Step 6: Move to next station

Step 7: Inspect incoming part

Step 8: Apply thread locker