WORK INSTRUCTION

Document ID: DOC-0000742
Project: PRJ-017
Uploaded on: 2023-10-26
Uploaded by: user022
Export class: EAR99

Assembly of P-100936 at plant PLT02

Part Number: P-100936
Revision: A.1
Plant: PLT02
Station: ST-92
Torque (Nm): 2.5
Cycle time (s): 234

Step 1: Fit fasteners

Step 2: Move to next station

Step 3: Inspect incoming part

Step 4: Fit fasteners

Step 5: Clean mating surface

Step 6: Torque to specification

Step 7: Visual check

Step 8: Move to next station