WORK INSTRUCTION

Document ID: DOC-0000870
Project: PRJ-039
Uploaded on: 2023-12-30
Uploaded by: user071
Export class: EAR99

Assembly of P-100226 at plant PLT04

Part Number: P-100226
Revision: B.1
Plant: PLT04
Station: ST-33
Torque (Nm): 20
Cycle time (s): 241

Step 1: Apply thread locker

Step 2: Inspect incoming part

Step 3: Fit fasteners

Step 4: Inspect incoming part

Step 5: Visual check

Step 6: Apply thread locker

Step 7: Move to next station

Assembly of P-100136 at plant PLT02

Part Number: P-100136
Revision: C.1
Plant: PLT02
Station: ST-92
Torque (Nm): 5
Cycle time (s): 285

Step 1: Apply thread locker

Step 2: Fit fasteners

Step 3: Record result

Step 4: Clean mating surface

Step 5: Fit fasteners

Step 6: Apply thread locker