WORK INSTRUCTION

Document ID: DOC-0000891
Project: PRJ-030
Uploaded on: 2024-01-14
Uploaded by: user054
Export class: EAR99

Assembly of P-100113 at plant PLT02

Part Number: P-100113
Revision: C.1
Plant: PLT02
Station: ST-22
Torque (Nm): 2.5
Cycle time (s): 247

Step 1: Move to next station

Step 2: Visual check

Step 3: Apply thread locker

Step 4: Apply thread locker

Step 5: Visual check

Assembly of P-101475 at plant PLT01

Part Number: P-101475
Revision: A.1
Plant: PLT01
Station: ST-77
Torque (Nm): 12
Cycle time (s): 37

Step 1: Fit fasteners

Step 2: Apply thread locker

Step 3: Visual check

Step 4: Move to next station

Step 5: Visual check

Step 6: Fit fasteners

Step 7: Move to next station