WORK INSTRUCTION

Document ID: DOC-0000951
Project: PRJ-006
Uploaded on: 2024-02-13
Uploaded by: user163
Export class: EAR99

Assembly of P-101400 at plant PLT03

Part Number: P-101400
Revision: A.1
Plant: PLT03
Station: ST-24
Torque (Nm): 20
Cycle time (s): 87

Step 1: Inspect incoming part

Step 2: Apply thread locker

Step 3: Fit fasteners

Step 4: Inspect incoming part

Step 5: Clean mating surface

Step 6: Torque to specification

Step 7: Apply thread locker