WORK INSTRUCTION

Document ID: DOC-0001055
Project: PRJ-007
Uploaded on: 2024-04-08
Uploaded by: user092
Export class: EAR99

Assembly of P-100853 at plant PLT02

Part Number: P-100853
Revision: A.1
Plant: PLT02
Station: ST-51
Torque (Nm): 12
Cycle time (s): 128

Step 1: Apply thread locker

Step 2: Clean mating surface

Step 3: Move to next station

Step 4: Apply thread locker

Step 5: Fit fasteners

Step 6: Move to next station