WORK INSTRUCTION

Document ID: DOC-0001063
Project: PRJ-027
Uploaded on: 2024-04-11
Uploaded by: user041
Export class: EAR99

Assembly of P-101657 at plant PLT04

Part Number: P-101657
Revision: A.1
Plant: PLT04
Station: ST-26
Torque (Nm): 8
Cycle time (s): 208

Step 1: Fit fasteners

Step 2: Apply thread locker

Step 3: Fit fasteners

Step 4: Clean mating surface

Step 5: Torque to specification

Step 6: Clean mating surface

Step 7: Torque to specification

Assembly of P-100974 at plant PLT04

Part Number: P-100974
Revision: A.1
Plant: PLT04
Station: ST-44
Torque (Nm): 5
Cycle time (s): 56

Step 1: Apply thread locker

Step 2: Move to next station

Step 3: Apply thread locker

Step 4: Torque to specification

Step 5: Visual check

Step 6: Apply thread locker

Step 7: Move to next station